


MAXXMAR WINDOW FASHIONS
 150 Bantor Road, Toronto, Ontario M9M 1H1
 Tel: 416-742-6299 - Toll Free: 1-866-916-6299
 Fax: 416-742-1772
 www.maxxmar.com




Dream Shade Motorization Instructions

1. Motor Introduction



2. Pairing Motor to Remote




WARNING STRANGULATION HAZARD

YOUNG CHILDREN CAN BE STRANGLED BY CORDS. IMMEDIATELY REMOVE THIS PRODUCT IF A CORD LONGER THAN 22 CM OR A LOOP EXCEEDING 44 CM AROUND BECOMES ACCESSIBLE.


MISE EN GARDE RISQUE D'ÉTRANGLEMENT

LES ENFANTS EN BAS ÂGE PEUVENT S'ÉTRANGLER AVEC DES CORDES. ENLEVEZ IMMÉDIATEMENT CE PRODUIT SI UNE CORDE MESURANT PLUS DE 22 CM DEVIENT ACCESSIBLE OU SI LE CONTOUR D'UNE BOUCLE DE PLUS DE 44 CM DEVIENT ACCESSIBLE.


3. Adding Channel




4. Change direction of opening and closing



5. Deleting Limits




6. Set limit of opening and closing



Note: If blinds degree is not 90 (means not perpendicular to the track) when you set limit of opening and closing, please press transmitter Tilt button to adjust to 90 degrees. If not, the misaligned left and right blinds may destroy the runners when closing.

7. Set limit of tilt

Note: When setting the tilt limit, the blinds must run to the fully closed position, otherwise the tilt limit cannot be set.



8. Factory reset - clear all setting on the motor

